

PD ISO/TS 18870:2014



BSI Standards Publication

Lifts (elevators) — Requirements for lifts used to assist in building evacuation

bsi.

...making excellence a habit.™

National foreword

This Published Document is the UK implementation of ISO/TS 18870:2014.

The UK participation in its preparation was entrusted to Technical Committee MHE/4, Lifts, hoists and escalators.

A list of organizations represented on this committee can be obtained on request to its secretary.

This publication does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

© The British Standards Institution 2014. Published by BSI Standards Limited 2014

ISBN 978 0 580 85218 3

ICS 91.140.90

Compliance with a British Standard cannot confer immunity from legal obligations.

This Published Document was published under the authority of the Standards Policy and Strategy Committee on 31 August 2014.

Amendments issued since publication

Date	Text affected
------	---------------

Lifts (elevators) — Requirements for lifts used to assist in building evacuation

*Ascenseurs — Exigences pour les ascenseurs utilisés en cas
d'évacuation de bâtiments*





COPYRIGHT PROTECTED DOCUMENT

© ISO 2014

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Contents

Page

Foreword	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Automatic evacuation lift specification	3
4.1 Determining the number and size of lifts.....	3
4.2 Protection of lift equipment.....	3
4.3 Waiting and travelling environment for users.....	4
4.4 Removal or suspension of lifts from evacuation service.....	4
4.5 Lift system reliability.....	4
4.6 Automatic recovery system.....	4
4.7 Remote lift car surveillance.....	5
4.8 Communication system requirements.....	5
4.9 Lift signs and passenger announcements.....	6
4.10 Prevention and detection of car overloading.....	6
4.11 Initiation of evacuation service.....	6
4.12 Description of evacuation service.....	6
4.13 Removal of lifts cars from service.....	8
4.14 Change of main evacuation exit floor (MEEF).....	9
4.15 Cancellation of evacuation service.....	9
5 Information to be provided to the building owner	9
6 Other information to be provided	10
Annex A (informative) Building design considerations for automatic lift evacuation specification	11
Annex B (informative) Information to be provided	19
Bibliography	21

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation on the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the WTO principles in the Technical Barriers to Trade (TBT) see the following URL: Foreword - Supplementary information

The committee responsible for this document is ISO/TC 178, *Lifts, escalators, and moving walks*.

Introduction

This Technical Specification has been prepared in response to ISO/TC 178 Resolution 273/2007 in which the Technical Committee requested that WG 6 undertake to write a specification for lift features that if incorporated into an appropriate lift would enable it to be used in safety to evacuate persons from a building that was suitably designed.

This work results from a detailed study undertaken by TC 178/WG6 into the feasibility of using lifts for evacuation of persons. The study ISO/TR 25743 indicated that it was feasible to use lifts, provided that certain features were incorporated in the lift and also in the building.

Lift engineers and other specialists have been involved in the production of this specification.

It has been recognized that lift engineers are not experts in building design or fire engineering. The writing of this Technical Specification does not indicate if it is acceptable or permitted to use lifts for building evacuations. It only indicates the features required should those persons responsible wish to make such a decision. This Technical Specification does not define, in any detail, building features that will have to be provided in conjunction with a lift intended to be used for evacuation. Its aim is to make clear to those persons involved in building design and fire engineering the issues that they shall address to enable the lift to be used safely.

There are many reasons why a building might need to be evacuated, such as a fire, explosion, chemical or biological attack, flooding, storm damage, earthquake, etc. Not all of these are relevant to every building and other hazardous situations, while existing, are so unlikely to occur that they can be disregarded. Designers of buildings have to determine if a particular hazard is sufficiently great as to require addressing.

If, for example, a small office block is being designed that will be located in a mid-town area, it is within the realm of possibility that it could be subjected to an explosion or chemical attack (terrorism). It is not, however, very likely to be the case unless it has some particular reason to make it vulnerable. In most cases, the risk of these events is probably so low as to make it unnecessary for them to be addressed.

If the building is to be the headquarters of National Security, this will increase the likelihood of it being subjected to some form of attack. It might be necessary to consider the effects of an explosion in or close to the building or a chemical agent being introduced into the building.

Clearly, a building constructed in an area where earthquakes do not normally occur need not have provisions made for such an event.

If a building is to be built in the centre of a major city to form a prestigious landmark, it might be essential to consider all likely events that could occur.

The designer of the building has to determine, by risk assessment or other methods, what hazardous events need to be reasonably addressed. Once this is completed, ISO/TR 25743 can be used to understand the lift and building features that might be required for each evacuation scenario envisaged.

A lift or lifts can enable disabled persons to evacuate a building in relative ease, but if it is thought, lifts could play a role in general evacuation, they might or might not make a significant contribution to reducing the general evacuation time. It will depend on the building size, number of lifts, etc.

This Technical Specification defines lift requirements to address common hazards that all users could be exposed to if lifts are used for evacuation.

Even if it is thought that lifts could play a part in a general evacuation, it might prove to be uneconomical. It is not suggested for lifts to replace or change the requirements for escape stairs, and that using lifts instead of stairs can increase evacuation times in many building designs. The intention is to allow lifts to play a positive role in assisting and improving the efficiency of the building evacuation strategy.

This Technical Specification is divided into sections covering the key items that have to be addressed. There is no priority intended from the order in which the items are listed.

Lifts (elevators) — Requirements for lifts used to assist in building evacuation

1 Scope

This Technical Specification details requirements for passenger carrying lifts, which are installed in buildings having a suitable comprehensive building evacuation strategy. It does not define building requirements that will have to be provided as part of the overall evacuation strategy for the building.

Excluded from this Technical Specification are the following:

- details of a building evacuation strategy;
- details of building features to reduce risks or eliminate hazards;
- national building requirements which might demand special features.

2 Normative references

The following documents, in whole or in part, are normatively referenced in this document and are indispensable for its application. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 4190-5, *Lift (Elevator) installation — Part 5: Control devices, signals and additional fittings*

3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

3.1

Alternative Evacuation Exit Floor

AEEF

level defined by the building designer to be used for evacuation when systems or management determine it should be used

3.2

Building Management System

BMS

system capable of making appropriate decisions based on information sent to it

3.3

chemical incident

introduction of a gas, chemical, bacterial agent, or substance into the building

3.4

building management

persons or organization responsible for ensuring the day-to-day safe efficient running of the building and for ensuring the building is safely evacuated in line with the evacuation strategy

3.5

ETA

estimated time of arrival of the lift